


Magnetic Graphic Hanging Kit Instructions for the Eurostyle Pop Up System




Insert magnet into hole in each graphic hanging strip or graphic hanging square as shown.



Remove the backing paper to reveal the self adhesive strip. Magnet will tend to drop out when you turn the strip over to affix, so gently bend the strip's edges up and slide the magnet into position underneath before finally affixing to rear of graphic panel.



On the main panels the graphic hanging rail attaches directly to the top edge of the graphic. Ensure the triangular recess (a) is facing downwards as in the picture above.



For the end curve panels apply graphic hanging squares directly onto the top corners of the graphic. The triangle (a) should face downwards. If in doubt carefully study the picture above. It is important that the end curve fixings are exactly positioned the same way round as the front face graphic rail.

